


RAPTOR FEETS REMOVAL

STEP 1

Please use the designated access point shown in the image to remove the feet.



RAPTOR FEETS INSERT

STEP 2

After removing the feet, proceed to attach the new foot to the desired location.

Ensure that the area where it will be attached is clean to prevent any surface irregularities.

The new foot is self-adhesive, eliminating the need for glue.

